

Alternate Pigtail Installation and Use

This pigtail is for vehicles with non-standard wiring applications. The lamp you have purchased is wired to mate with an industry-standard H4 wiring connector. Your vehicle may not be wired to industry standard:




If your vehicle's high beam, low beam and ground wire(s) are positioned differently than the above diagram, you should use this pigtail adaptor to realign the connectors in the proper location for your vehicle.

Step 1:
Identify the current location of the ground, low beam and high beam on your vehicle.

Step 2: Match up the proper wire of the pigtail and snap each into the included plastic housing that corresponds to your vehicle harness.

Step 3: Insert the pre-wired lamp plug into the adaptor pigtail, then plug the adaptor pigtail into the matching vehicle harness.



For technical support dial 1-800-628-0809 or email david.kendall@grote.com
Caution: Metal tabs are sharp, cut hazard